

Automated Beverage System

Card No: BE021

Clean and Sanitise the Ice Hopper

Frequency	Weekly
Models	Cornelius ABS
Estimated Time to Complete	40 minutes

Health and Safety Hazards

-  Chemicals
-  Slippery floors/tripping
-  Moving Components

Food Safety

-  Wash and dry hands **before and after** performing this task
-  Ensure nuts, bolts & screws are tight
-  Inspect equipment. Do not use if damaged

Equipment and Cleaning chemicals



Important Information - before you start :

Always switch OFF the ABS before performing any of the actions described below.
If an ice maker is installed onto the ABS, always first perform the Ice Maker cleaning procedures prior to start with the ABS ice hopper cleaning.

Please refer to the Manufacturer’s Maintenance Cards for performing the Ice Makers periodic Cleaning-, Sanitation- and De-scaling procedures.

- 1 Turn off ABS, the switch is located on the lower left side of the unit’s front panel.



- 2 Remove the top over – or open the lid of the ice maker adapter.



- 3 Remove all ice from the hopper using a plastic scoop. Discard all removed ice.
WARNING : Be careful when standing on the step tool.



- 4 Remove the agitator retainer by unscrewing it counter-clockwise.



5

Lift off the agitator disk. Clean the agitator disk and retainer using the 4 - steps cleaning method.



6

Clean the inside of the hopper using Multi-Surface & Glass Cleaner and a sanitised red border cloth. Spray SolidSense Sanitizer and let air dry.



7

Reinstall the agitator disk and retainer.



8

Refill the ice bin with fresh ice, OR switch on the ABS Ice maker.



9

Replace the top over – or close the lid of the ice maker adapter.



10

Turn ON the ABS, the switch is located on the lower left side of the unit's front panel.



11

Refill the ice chute by pressing the button labelled "EXTRA ICE".



12

Check the display if any orders are pending. Press the AUTO button.

