

# Clean the Toaster

# Clean the Belts

To ensure the unit is clean when toasting buns.

Frequency

Daily

Models

Toaster

Estimated Time to Complete

20 minutes

### Health and Safety Hazards

-  Chemicals
-  Electricity

### Food Safety

-  Wash and dry hands **before and after** performing this task
-  Ensure nuts, bolts & screws are tight
-  Inspect equipment. Do not use if damaged

### Equipment

- 


1. Red Cloth
- 

2. Gloves, neoprene
- 

3. Kay surface sanitiser
- 


4. Mutli surface cleaner

1




Turn the toaster's power switch to the off position. The toaster enters a cool-down mode and will automatically shut down when complete.

2




Wait until shut down is complete and unplug toaster. Remove Heat Shield Bun Feeder with heat-resistant gloves.

3



Clean the outside surfaces of the toaster with a red border cloth and Multi surface cleaner. Allow to air dry.

4



Remove the front and rear conveyor cover by lifting up and away from the unit.

**5**

Inspect the front belt for any tears, discoloration, or damage to the belt snaps. Replace all belts on the toaster if any of the belts are damaged.




**6**

If the front belt is in good condition, spray clean with surface sanitizer. Wipe the toaster belt clean with red border cloth. Allow to air dry




**7**


Inspect the rear belts for any tears, discoloration, or damage to the belt snaps. Replace all belts on the toaster if any of the belts are damaged.



**8**




Wipe with red border cloth. Wipe the rear belts clean. Wipe rear belts with a clean red boarder cloth.




Clean the bun feeder using the 4 step cleaning method

**9**




Reinstall the front and rear conveyor covers onto the unit.

**10**



Reinstall the bun feeder.

**11**



Plug in the power cord. Turn the unit on.