

Automated Beverage System

Card No: BE020

Clean ABS

Frequency

Daily

Models

Cornelius ABS

Estimated Time to Complete

15 Minutes

Health and Safety Hazards



Chemicals



Slippery floors/tripping

Food Safety



Wash and dry hands **before and after** performing this task



Ensure nuts, bolts & screws are tight




Inspect equipment. Do not use if damaged

Equipment and Cleaning chemicals



1

Press the 'Manual Auto' button in the lower left hand corner of the touchpad to place unit in Manual mode.



2

Loosen the three thumbscrews that hold the cup conveyor cover in place by turning them counter-clock wise. Remove the cup conveyor cover by lifting it up. Remove conveyor assembly by lifting it up.



3

Remove the grill from the drip tray and set it aside. Remove any foreign objects from the drip tray.



4

Use a clean, sanitised red border cloth and Multi-Surface & Glass Cleaner to clean the drip tray. Repeat with SolidSense Sanitizer.



5

Pour carbonated water from dispenser into the drip tray. Check that the drip tray drains properly. If drain pan is slow draining service may be required.



6

Clean and sanitise the conveyor, grill and cover at the three-compartment-sink using 4 - steps cleaning method.



7

Ensure the conveyor drive seal or water deflector is in place. If it is missing order and re-placed immediately. Failure to replace in a timely manner will result in degradation of the drip tray insulation.



8

Roll the end of a paper towel to a point and dip it in carbonated water. Wipe both sensors which are located on the left side of drain pan near position A.
Do not use a cloth on sensor, it may leave film on sensor lens.



9

Reinstall grill. Reinstall conveyor with drive assembly on left. Further instructions can be found on the front upper panel of the ABS.



10

Reinstall cover and tighten the three thumbscrews by hand until snug.



11

Remove the nozzle from the dispenser by turning clockwise and pulling down. Remove the diffuser (clear) and diffuser ring (white) by pulling down.



12

Wipe down the diffuser area with a clean, sanitised red border cloth. Brush the diffuser area thoroughly with the nylon-bristled brush provided.



13

Clean the diffuser and nozzle thoroughly with the nylon-bristled brush and warm water, then clean using 4-step cleaning method.



14

Equipment Alert

Do not clean the holes in the bottom of the diffuser.



15

Push the diffuser back into position. Reinstall the nozzle by pushing the nozzle up and turn counter-clockwise until it is firmly in place. Pull downwards to make sure it is correctly in place.



16

Wipe the outside of the ABS with a clean, sanitised red border cloth and Multi Surface & Glass Cleaner. Use a non-scratch pad to remove heavy soils.



17

Check the display if any orders are pending. To empty the buffer, press the UP arrow to cancel orders, and press the ENTER button to confirm. Press the AUTO button.

